

Pemko Residential Threshold

The global leader in
door opening solutions


Applies to the following products:

324, 3261, 326, 327

Installation Instructions:

1. Measure, mark, and trim sill nosing to desired length. If necessary, trim (notch) around door jambs.
2. Secure using construction grade adhesive (or caulking) to bond metal nosing to concrete sill to be covered (adhesive not included).
3. If intended for use with pre-installed threshold, loosen threshold screws, slip top leg of nosing under outside leg of threshold and adhere as described in step 2.

Tools Required:



Testing/Ratings:

www.pemko.com

MEMPHIS, TN USA	VENTURA, CA USA	VANCOUVER, BC CA	TORONTO, ON CA
P: 800 824-3018	P: 800 283-9988	P: 877 535-7888	P: 877 535-7888
F: 800 243-3656	F: 800 283-4050	F: 877 535-7444	F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

RT19_WEBINS
Rev 3 - 01.25.17
Page 1 of 1