

PERIMETER GASKETING

Applies to the following products:


29313_TF, 29321_TF

Testing/Ratings:

BHMA
CERTIFIED



Tools Required:



Installation Instructions:

1. Can be installed on a wood or metal frame.
2. Measure, mark and trim to length. Close door and position so that seal makes light even contact with door.
3. Drill pilot holes in stop at marks.
4. Secure with supplied screws.
5. Open and close door several times to check weatherstrip fit and seal.
6. To adjust, loosen screws, re-position weatherstrip, and tighten screws.
7. Snap on cover.