


# DOOR BOTTOMS

Applies to the following door bottom:

**3151SSN**

## Tools Required:



## Installation Instructions:

1. Trim to door width.
2. Trim seal to 1/16" longer than the trimmed housing on each end.
2. Locate at door bottom and ensure seal with the threshold.
3. Fasten with screws provided.