

## **PERIMETER GASKETING**

Applies to the following products:

322\_SN, 350\_SPK, 350\_SR

## **Testing/Ratings:**







Gasketing material for fire doors intended for application to listed steel frames and/or classified steel covered composite, hollow metal doors rated up to and including 3 hours; wood and plastic covered composite doors rated up to and including 1-1/2 hours; and wood core doors rated for 20 minutes.

## **Tools Required:**



## **Installation Instructions:**

- 1. Can be installed on a wood or metal frame.
- 2. Measure, mark and trim piece to length. Close door and position so that seal makes light even contact with door. Mark in center of holes.
- 3. Drill pilot holes in stop at marks.
- 4. Secure piece to stop with supplied screws.
- 5. Open and close door several times to check jamb weatherstrip fit and seal.
- 6. Adjust the adjustment screw as necessary to fit seal properly.