

FLOOR MOLDING, TRIM & HANDYSHAPES


Applies to the following products:

2132, 2134, 2218, 2219

Testing/Ratings:



Tools Required:



Installation Instructions:



↑
**Trims
Carpet
Edge**

1. Measure length of carpet or seam to be covered.
2. Measure, mark and trim carpet bar to length using tin snips or hacksaw.
3. Place carpet bar over carpet or seam and nail in place:
 - a. Wood floor installation: secure to floor with supplied nails.
 - b. Concrete floor installation: secure to floor using rawl pugs (rawl plugs not included).