



ASSA ABLOY

## FLOOR MOLDING, TRIM & HANDYSHAPES

Applies to the following products:

**2250W, 2175W, 2300W, 2219W, 2350W, 2500W**

### Tools Required:



### Installation Instructions:



↑  
**Covers  
Floor  
Seams**

1. Measure length of seam to be covered.
2. Measure, mark and trim product to length using tin snips or hacksaw.
3. Place product over seam and screw in place:
  - a. Wood floor installation: secure to floor with supplied screws.
  - b. Concrete floor installation: secure to floor using rawl pugs (rawl plugs not included).

[www.pemko.com](http://www.pemko.com)

© 2010 Pemko Manufacturing Co.  
FM6\_WEBINS  
Rev 1 - 02.09.10