

## **FLOOR MOLDING, TRIM & HANDYSHAPES**


**Applies to the following product:**

**2604W**

### **Tools Required:**



### **Installation Instructions:**



1. Measure length of floor edge to be covered.
2. Measure, mark and trim edging to length using tin snips or hacksaw.
3. Place carpet bar over carpet or seam and nail in place:
  - a. Wood floor installation: secure to floor with supplied screws.
  - b. Concrete floor installation: secure to floor using rawl pugs (rawl plugs not included).