



SET SCREW INSTALLATION

1. Using an Allen wrench, insert two (2) set screws into drilled and tapped holes in base of the unit.
2. Adjust projection of set screws to obtain required degree of drop for the arm.
3. The arm can be adjusted after installation by removing the base mounting screw nearest the set screws and swinging base into opening. (Doors should be open).
4. Replace base mounting screw and test for normal operation.

ROLLER INSTALLATION

1. Select the hole nearest top of door, so when installed, nylon washer will ride over strike plate as inactive door closes.
2. Install the shoulder screw and nylon washer into drilled and tapped hole on outside of the short arm.

CAUTION:

1. Roller must be at bottom of cam. Relocate to change hand.
2. If inactive door is equipped with flush bolt, be sure that strike plate clears bolt.
3. Minimum 2" headroom required.

Not To Scale

Template No.
T-576
Rev. 1/29/09

NOTE: Rockwood reserves the right to make product changes and is not responsible for obsolete template errors. To ensure your template is current, please visit our website at www.rockwoodmfg.com or call us at 800-458-2424.