

QUICK-KIT COMPONENTS

To add new keyways to your machine, see below table. Find the manufacturer you want in the first column and order the parts in that row. You do NOT need any duplicate parts. Ex: If you already have dual capabilities, you do NOT need an additional 2026RH/LH Depth Driver or RY2007 Top Vise Jaw.

MFG.	DEPTH SELECTOR ASSEMBLY	SPACE BAR ASSEMBLY	PUNCH & DIE ASSEMBLY	DEPTH DRIVER (RH or LH)	TIP STOP ASSEMBLY	TOP SHOULDER STOP ASSEMBLY	TOP VISE JAW
RY2000ARW ARROW	RY5070DS	RY4070SB	RY6070PD	RY2026LH		RY2075TSS	RY2007AF
RY2000M-M1 MASTER	RY5071DS	RY4071SB	RY6071PD	RY2026LH		RY2075TSS	RY2007 RY2006M1*
RY2000CO70 CORBIN	RY5073DS	RY4073SB	RY6073PD	RY2026LH		RY2075TSS	RY2007
RY2000DEX DEXTER	RY5074DS	RY4074SB	RY6074PD	RY2026LH		RY2075TSS	RY2007
RY2000KMARK KEYMARK	RY5075DS	RY4075SB	RY6075PD	RY2026LH		RY2075TSS	RY2007B RY2006KM*
RY2000A2/A3/A4 BEST/I-CORE	RY5076DS RY5077DS RY5078DS	RY4078SB	RY6078PD	RY2026LH	RY2015TS		RY2007B
RY2000KW KWIKSET	RY5079DS	RY4079SB	RY6079PD	RY2026LH			RY2007
RY2000SCH SCHLAGE CLASSIC, REVERSE, AND EVEREST	RY5090DS	RY4090SB	RY6090PD	RY2026RH (LH for reverse)			RY2007
RY2000WEI WEISER	RY5094DS	RY4094SB	RY6094PD	RY2026LH		RY2075TSS	RY2007
RY2000WES WESLOCK	RY5095DS	RY4095SB	RY6095PD	RY2026LH		RY2075TSS	RY2007
RY2000MX4_ MEDECO	CONTACT RYTAN FOR PART NUMBERS AND INFORMATION						

ALL ASSEMBLIES COME WITH HARDWARE NECESSARY FOR INSTALLATION

*KEYMARK & MASTER M1 require custom vise bases that differs from all other machine models

CONTACT US for information on unlisted keyways, and keyways in development.