

# How to Install Your Wunda Chair Handles

Your Wunda Chair handles are easy to install, using the Allen wrench provided with your parts kit.

## PARTS INCLUDED:

Description	Part Number	Qty
Wunda Chair Receivers	616-276	2
Wunda Chair Handles	616-277	2
Chair Handle Plunger Knobs	GEN9081	2
5/32" Allen wrench	GEN9282	1
1/4" Flat Washers	GEN9204	8

## ATTACHING RECEIVERS

1. Begin on the side that does not have the cable and pin assembly.

Four black, buttonhead screws come preinserted on each side of the chair. Three are 7/8" long and one is 1-1/2" long. Remove all and save for re-use.



Place one of the receivers against the side of the chair, aligning the holes in the square tabs with the holes pre-drilled into the chair. The round, threaded hole on the receiver should be at the top.

2. Place one 1/4" washer on each of the 8 buttonhead screws.

Beginning with the upper two screws, install a 7/8" buttonhead screw and washer assembly into the hole closest to the front of the chair. Install a 1-1/2" buttonhead screw and washer assembly into the upper back hole. Push the screws through the wooden side of the chair and use the allen wrench to engage the threads into the propeller nuts. Do not tighten completely yet.



3. Install two 7/8" buttonhead screw and washer assemblies into the two holes of the lower receiver tab. Push the screws through the wooden side of the chair and use the allen wrench to engage the threads into the propeller nuts.

Tighten these screws firmly, then tighten the upper screws.

4. On the other side of the chair, temporarily remove the pre-inserted screws and the cable and pin assembly. Install the receiver, again using the 1-1/2" screw in the upper back position. Use a 7/8" screw for the upper front position, re-installing the cable and pin assembly so that it remains in the upper front position, secured between the receiver and the head of the screw. Do not tighten completely yet.

5. Install the bottom two 7/8" screws for the receiver on this side of the chair, tightening firmly. Then tighten the upper two screws.

6. Finally, screw the large, black, spring-loaded knobs into the threaded hole at the top of each receiver. Do not tighten all the way as some slack is needed to allow entry of the handles.



## INSTALLING HANDLES INTO RECEIVERS

1. Pulling out on the spring-loaded black knob, slide the end of each handle down into the receivers. The black knobs are spring-loaded and must be held out to allow the handle to slide into the receiver. When one of the holes in the handle is located, the black knob locks into place. To further secure it, tighten the black knob until snug.



Questions? Call Balanced Body technical support at 1-800-745-2837 (USA and Canada) or +1-916-388-2838 (all other countries). Email: [info@pilates.com](mailto:info@pilates.com).