

HOW TO

Install a Solvent-Weld Shower Drain



Secure shower drain to shower floor. Use silicone sealant for water tight seal.



Tighten locking nut to secure shower drain to shower floor.



Measure distance from floor to stop inside of shower drain. Cut pipe to measured height.



Apply solvent cement to secure shower drain and pipe.

HOW TO Replace A Shower Strainer



Remove old strainer by using a flat-head screwdriver to pry loose from shower drain. If a snap-in strainer. Use Philips-head screwdriver to remove screws if a screw-in strainer.



Insert new strainer by snapping into shower drain.