



Heavy Duty PowerBar Mini Strut™


Installation Guide




Locate holes on bracket ends and secure bracket to 3/8" threaded rod using washers and 3/8" nuts. If desired, hardware can be installed both above and below bracket. Install double nut if specified.



Position tube or conduit into base of TouchDown clamp.



Slide TouchDown™ clamps to desired location within the bracket.



Ratchet bridge of TouchDown clamps down over both posts evenly.

Made in USA

24110 South Peculiar Drive
Peculiar, Missouri 64078
P 1.800.821.3944
F 1.800.758.5950

UPC®
File 3163




Heavy Duty PowerBar Mini Strut™

Installation Guide



For larger pipe sizes or when insulation is required, use the TouchDown II™ clamp (purchase separately) and install on the bracket with the screws provided.



Additional TouchDown clamps can be purchased in bulk and added to the bracket before installing onto threaded rod. Ideal when running flexible gas lines.



Plenum Safe™ TouchDown Clamps are also available in polyvinylidene fluoride (PVDF) material for ASTM E84 requirements.

523F5500 – E84 PowerBar TouchDown for ½" through 1" CTS.

550F20 – E84 TouchDown II for ½" thru 2" CTS.