

# SCHUMACHER

## Camden Ottomans



Camden Ottoman  
SH011E



Camden Skirted Ottoman  
SH011

# Camden Ottomans – SH011E & SH011

|  |  |
|--|--|
| <i>Standard Dimensions</i>   | 34"W x 23"D x 21"H   |
| <i>Standard Features</i>   | Semi Attached Box Edge Seat Cushion<br>Cushion Fill: Ultralux or Spring Down<br>Self Welt<br>SH011E: Antique Brass Ferrules & Casters<br>SH011: 10" Dressmaker Skirt |
| <i>Custom Options</i>  | Customizable Dimensions<br>SH011E: Nailhead Detailing: See Nailhead Chart<br>Legs: Finished Peg Post<br>SH011: Built to Floor  |
| Please See a Customer Service Representative for Custom Quotations |  |
| <i>Finish Options</i>  | Wood Finish: See Finish Chart  |



## Ottoman – SH011E

Required COM YARDAGE  
4.5 Yards of 54" Plain Fabric

Optional COM YARDAGE  
11 Yards of Contrast Cord – All Welt  
6.5 Yards of Contrast Cord – Seat Cushion Only

AS SHOWN  
Upholstery: Lismore Linen Plain in Oatmeal, 62011. Self Welt.  
Wood Finish: #26 Antique Walnut.  
Ferrules & Casters Finish: Antique Brass.



## Skirted Ottoman – SH011

Required COM YARDAGE  
5.5 Yards of 54" Plain Fabric

Optional COM YARDAGE  
10 Yards of Contrast Cord – All Welt  
6.5 Yards of Contrast Cord – Seat Cushion Only  
3.5 Yards of Contrast Cord – Top of Skirt  
5.5 Yards of Tape or Gimp – Bottom of Skirt

AS SHOWN  
Upholstery: Corsica Weave in Linen, 51343. Self Welt.

## Camden Line



Camden Sofa  
SH301E



Camden Skirted Sofa  
SH301



Camden Sleeper Sofa  
SH301S



Camden Loveseat  
SH201E



Camden Skirted  
Loveseat SH201



Camden Ottoman  
SH011E



Camden Skirted  
Ottoman SH011

See Sofas, Loveseats & Chaises for Additional Camden Offerings