

# FIRST Bumper Logo



1. Iron setting on high
2. Thin cloth in between transfer backing and iron
3. Apply pressure and iron in a circular motion
4. Check by peeling back. If it comes off cleanly, you're done; if not, keep ironing checking frequently.