

## ROVER RETREAT HOUSE CONSTRUCTION INSTRUCTIONS

**Open carton and verify panels and pre-assembles as they appear on diagram**

**STEP 1.** Attach both sides to front panel using 2 fastener sets on each side with the nuts and washer positioned as indicated, thread nuts loosely.

**STEP 2.** Attach back panel to sides in the same manner as the front panel. Tighten all nuts securely.

**STEP 3.** Drop in floor frame on front and back supports, with slats parallel to sides.

**STEP 4.** Apply liquid nail or similar adhesive to top edge on front and back.

**STEP 5.** Position roof panels as indicated on diagram. Painted edges facing out.

**STEP 6.** Apply liquid nail or similar adhesive along peak of roof panels and attach roof cap.

**STEP 7.** Attach pre-assembled deck's panels using fasteners as indicate on diagram.

Optional: You may use wire brad nails to attach roof top deck. BE SURE NOT TO LEAVE EXPOSED NAILS

