

Retrofit Counterweight for Universal Storage 1-Hi and 2-Hi Lateral Files with Feet prior to Feb. 21, 2020

NOTE: If you have a 1-Hi case with Feet or a 2-Hi case with Feet which was manufactured prior to February 21, 2020, then this Retrofit Counterweight RAACWR is required in addition to the counterweights shown in Assembly Direction P/N 1396566001 / Doc # 148861.

1. Using four (4) #10 x 3/4" self drilling screws (included), attach counterweight plate flush with rear feet as shown.

For files wider than 30W, the plate should be installed flush with either left or right rear foot (plate will not reach both feet simultaneously).

⚠ CAUTION

Please refer to the Steelcase Specification Guide for Storage for additional guidance on determining the correct counterweight package.

If you have a problem, question, or request, call your local dealer, or Steelcase Line 1 at **888.STEELCASE** (888.783.3522) for immediate action by people who want to help you.

(Outside the U.S.A., Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands, call: 1.616.247.2500)
Or visit our website: www.steelcase.com

© 2020 Steelcase Inc.
Grand Rapids, MI 49501
U.S.A.

Printed in U.S.A.

