

NOTE: If there is a shelf on either or both sides of the shelf in which the Coat Rod is being installed, remove the shelf and loosely assemble the Coat Rod before installing the shelf back on the frame.

1. Place first bracket assembly on one side of shelf.
For the 1-WIDE Coat Rod, it can be oriented on the shelf from side-to-side or front-to-back
2. Slide opening of tube assembly over tapped plate until the tube assembly spacer is flush against the bracket.
3. Slide the second bracket assembly on the other side of the shelf and locate the tapped plate through the opening on the tube assembly.
4. Press the assembly firmly together and lightly fasten together with
QTY = 2 – M4 countersunk screws. Slide the assembly to the desired position and tighten the screws to lock the Coat Rod in place.

