

JAY Rack

SKU 11-0001

Updated January 2013

Suspensz, Inc. Spacing Chart ®

| Boat Length | Ideal Tower Spacing (40%) | Min/Max spacing for each kayak (35% / 50%) |
|-------------|---------------------------|--------------------------------------------|
| 8' | 3' 2" | 2' 10" / 4' |
| 8' 6" | 3' 5" | 3' / 4' 3" |
| 9' | 3' 7" | 3' 2" / 4' 6" |
| 9' 6" | 3' 10" | 3' 4" / 4' 9" |
| 10' | 4' | 3' 6" / 5' |
| 10' 6" | 4' 2" | 3' 8" / 5' 3" |
| 11' | 4' 5" | 3' 10" / 5' 6" |
| 11' 6" | 4' 7" | 4' / 5' 9" |
| 12' | 4' 10" | 4' 2" / 6' |
| 12' 6" | 5' | 4' 5" / 6' 3" |
| 13' | 5' 2" | 4' 7" / 6' 6" |
| 13' 6" | 5' 5" | 4' 9" / 6' 9" |
| 14' | 5' 7" | 4' 11" / 7' |
| 14' 6" | 5' 10" | 5' 1" / 7' 3" |
| 15' | 6' | 5' 3" / 7' 6" |
| 15' 6" | 6' 2" | 5' 5" / 7' 9" |
| 16' | 6' 5" | 5' 7" / 8' |
| 16' 6" | 6' 7" | 5' 9" / 8' 3" |
| 17' | 6' 10" | 5' 11" / 8' 6" |
| 17' 6" | 7' | 6' 2" / 8' 9" |
| 18' | 7' 2" | 6' 4" / 9' |
| 18' 6" | 7' 5" | 6' 6" / 9' 3" |
| 19' | 7' 7" | 6' 8" / 9' 6" |
| 19' 6" | 7' 10" | 6' 10" / 9' 9" |
| 20' | 8' | 7' / 10' |
| 20' 6" | 8' 2" | 7' 2" / 10' 3" |
| 21' | 8' 5" | 7' 4" / 10' 6" |
| 21' 6" | 8' 7" | 7' 6" / 10' 9" |
| 22' | 8' 10" | 7' 8" / 11' |
| 22' 6" | 9' | 7' 11" / 11' 3" |



| Item # | Parts List | Qty |
|--------|--------------------------|-----|
| 1 | JAY Rack Arm with straps | 2 |
| 2 | Phillips Head Screw | 4 |

Tools required:

1. Measuring tape
2. Pencil to mark the hole positions
3. Electric drill to set the pilot holes
4. 3/16" Drill bit to set the pilot holes
5. Phillips Head Screwdriver
6. Bar of soap

Mounting Rack to Wall:

1. Use the Spacing Chart above as a guideline to determine the distance between each JAY Rack arm.
2. Be sure to mount the JAY Rack arms into a stud. **Screwing only into drywall is not sufficient and could result in injury to self and kayak.**
3. Pre-drill pilot hole for Phillips Head screw using 3/16" drill bit.
4. Rub bar of soap on the screw threads for ease of installation.
5. Mount each JAY Rack per the photo above.

Strap Adjustment and Use:

1. After racks are attached to the wall, place your boat on Suspension Straps positioning kayak on its side.
2. Adjust each strap using the Velcro fasteners so the strap holding the boat is suspended and not touching a hard surface.
3. Place safety strap over your boat, clip buckles together then pull safety straps to achieve a snug fit.

Our Pledge to you:

Suspensz products are guaranteed against defects in material and workmanship to the original owner for one year after purchase. Please contact Suspensz with any questions.

Toll-free: 866.787.7369

Fax: 770.518.8507

Email: info@suspensz.com

Contact Information

suspensz.com

Suspensz, Inc.

8725 Roswell Road #O-220

Atlanta, GA 30350

KAYAK-CANOE-SUP
storage & transport

suspensz®