

3-BOAT FRAME

Model # 31-0636

Model # 32-0603



PARTS LIST	
Qty	Name
2	Base
2	Base Post
2	Short Post
2	Long Post
8	Leveling Feet
8	Anchor - Leveling Feet
16	Hex Nut (on Leveling Feet)
4	Carriage Bolt - Base Post
12	Washer - All Posts
4	Lock Nut - Base Post
8	Hex Bolt - Post
8	Lock Washer - Post
12	Arm Mount Hardware
1	$\frac{1}{2}$ " Wrench
1	#5 Allen Wrench

Tools Needed: $\frac{1}{2}$ " Wrench and #5 Allen Wrench (included)

A cold beverage of your choice

Assembly

Step 1: Leveling Feet Attachment

Parts Needed: 2 *Bases*, 8 *Leveling Feet* (with *Hex Nuts*) and 8 *Anchors*

The *Anchor* is used when anchoring *Base* to floor, ground or dock. These may be omitted when *Base* is on a stable level surface/environment.

- With *Anchors*, remove first *Hex Nut* from *Leveling Foot*, place *Anchor* on foot and then screw *Hex Nut* back on. Screw into *Base*.
- Without *Anchors*, screw four *Leveling Feet* into welded nut in each *Base*.

Repeat for second tower.



Step 2: Base Post Attachment

Parts Needed: 2 *Base Posts*, 4 *Carriage Bolts*, 4 *Washers* and 4 *Lock Nuts*

Place *Base Post* over *Base* with square holes facing inside of *Base*. Insert *Carriage Bolts* from front so *Washer* and *Lock Nuts* are on back side.

Repeat for second tower.



Scan* to see
Video Instructions
for Assembly & Use
or

Visit Suspenz.com

"Video & Manual" page

*QR code reader app required

Rev. 11/15

FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

SUSPENZ®, INC.
8725 ROSWELL ROAD #0-220
ATLANTA GA 30350



CUSTOMER SERVICE: 770-518-0045
FAX: 770-518-8507
WEBSITE: WWW.SUSPENZ.COM

Assembly

Step 3: Post Attachment

Parts Needed: 2 *Short Posts*,
2 *Long Posts*, 8 *Hex Bolts*,
8 *Lock Washers* and 8 *Washers*

1. Insert *Short Post* into *Base Post*. Secure with *Hex Bolt*, *Lock Washer* and *Washer*.
2. Insert *Long Post* into *Short Post* and secure with *Hex Bolt*, *Lock Washer* and *Washer*.



Repeat for second tower.

If you have not yet opened your cold beverage, this would be an appropriate time to do so.

Attaching Arms to Frame

Parts Needed: 12 *Arm Mount Hardware*

3-BOAT RACK

All 3 sets of arms will be bolted directly to the front side of frame, using *Arm Mount Hardware Sets* (*Bolt*, 2 *Washers* and *Lock Nut*) included.

4 TO 6-BOAT DOUBLE-SIDED RACK

3 sets of arms will be bolted on the front side of frame and 1-3 sets will be attached to the back side of the frame using *Free-Standing Brackets* (Sold separately).

As a starting point, attach first set of arms to the lowest point possible to the front of frame. Place 1st boat onto the bottom set of arms. Position 2nd set of arms to allow space to lift the lower boat on and off the rack. Repeat this process on back side of frame.

Note: See Wall Rack Instruction Sheet for more details.

Tower Spacing

The length of your boat will determine tower spacing. Ideal rack spacing is 0.4 x boat length, this will help distribute the weight evenly.

Feet Adjustments

Adjust *Leveling Feet* so that both towers are level. Once the leveling feet are adjusted, screw the top *Hex Nut* up to base snugly, this is done so the foot will not change height.

Customizing your 3-Boat Frame

This 3-Boat Frame is completely modular making it super easy to add or modify it as your needs change. It easily expands to hold up to 6 kayaks, canoes, and/or SUPs. Add casters to make a rolling rack or add a paddle rack to store your paddles.

Check out the options to customize your rack at www.Suspenz.com



FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

OUR PLEDGE TO YOU

Suspenz® products are warranted for life against defects in material or workmanship to the original owner. Product must be used for its intended purpose under normal conditions. Please see visit www.Suspenz.com for more complete warranty information.

SUSPENZ®, INC.
8725 ROSWELL ROAD #0-220
ATLANTA GA 30350



CUSTOMER SERVICE: 770-518-0045
FAX: 770-518-8507
WEBSITE: WWW.SUSPENZ.COM