



# Hi-Port 2

Patent Pending

by  **StoreYourBoard.com™**

## THANK YOU FOR YOUR PURCHASE!

Please read all instructions before installing this product

### SAFETY INSTRUCTIONS & PRODUCT WARNINGS

It is the user's responsibility to ensure the safe and proper use of this product. StoreYourBoard, a Spire LLC company, is not responsible for damages or injuries related to installation or use, including improper or inadequate mounting. Wear eye protection during installation and check for electrical wiring in the wall before screwing or drilling into the wall. **Not a toy; not intended for children. Misuse of this product could result in serious injury or death.**

**Weight Limit.** Total weight in rack not to exceed **150 lbs.** Intended for use with surfboards, paddleboards and kayaks.

### WHAT'S INCLUDED

- 2 - Posts & sleeves
- 4 - Arms
- 2 - Locking pins
- 4 - Lag screws
- 4 - Washers

### WHAT YOU NEED

- Stud finder
- Drill with a small bit for pilot hole
- Socket or wrench

### MOUNTING INSTRUCTIONS

- 1. Locate ceiling joists.** Decide where to mount your Hi-Port 2 and locate ceiling joists. If the ceiling is covered with drywall use a stud finder to locate the joists. Do NOT mount to drywall only - the screws must be fully buried in sturdy anchor points.
- 2. Determine positions for the 2 posts.** Proper distance between posts will be determined by length of boards or kayaks being stored. Typical distance between posts will measure 6 - 10 feet. Boards or kayaks should overhang either side of the posts by a minimum of 12 inches.
- 3. Remove outer posts.** Slide outer posts off inner posts and set to the side.
- 4. Mark mounting points.** Hold the ceiling plate of the inner post against the ceiling joist with screw holes aligned along the length of the joist. Mark the joist at the locations of the holes.
- 5. Pre-drill mounting holes.** Using the drill bit, drill a hole into the joist at the first marked position. The hole should go 2-3 inches deep and will be narrower than the lag screws. Repeat for 2nd hole.
- 6. Mount posts to ceiling.** Attach first inner post by sending the first screw through the corresponding hole on the ceiling plate and into the first pre-drilled hole. Leave slightly loose for the moment. Repeat for 2nd screw. Tighten both screws against the plate. Repeat steps 5 & 6 for 2nd post.
- 7. Slide outer posts over inner posts.** Slide the first outer post over the first inner post and attach by aligning holes and sliding pin all the way through. Lock the pin in place with the attached wire gate. Repeat for 2nd. **Note:** Outer post arms may align parallel or perpendicular to ceiling joists.
- 8. Attach arms.** Slide arms over arm posts. Arms are locked in place when the spring lock clicks through the hole in the arm.