

Butter Spreader Pattern

1. Print and cut out each template
2. Use spray adhesive to fix to $\frac{1}{4}$ " plywood
3. Cut vertical profile
4. Tape pieces back together and cut horizontal profile

