



For bigger Alps volume pot,  
you do not prepare additional standoffs.  
Connect Hex nut - long and Hex nut - short directly,  
and attach Volume PCB on Hex nut - short,  
and fix the PCBs with extra screws included in the kit.

This is the same as TU-8340.