



rockGEAR™ — RS62140

Sway Bar End Link Kit – 10.8”

Fits: 2021 – 2018 Jeep Wrangler JL / JLU

WARNING

Carefully read, understand and follow the instructions provided in this manual, and keep it in a safe place for future reference. If you have any doubt whatsoever regarding the installation or maintenance of your Rancho suspension system, please see your retailer for assistance or advice. Failure to follow the warnings and instructions provided herein can result in the failure of the suspension system, or can cause you to lose control of your vehicle, resulting in an accident, severe personal injury or death.

These instructions should remain in the vehicle glove box for future reference.

P/N	DESCRIPTION	QTY.
RS176963	Rear Sway Bar End Link, 10.8”	1
RS82140	Instructions	1



Rancho Technical Department 1-800-325-8886.

REMOVE SWAY BAR END LINKS

- 1) Park vehicle on a level surface. Set the parking brake and chock wheels.
- 2) Remove sway bar end links from axle and sway bar.

SWAY BAR END LINK INSTALLATION.

End link ball stud and lower mounting bolt each use a different thread pitch. Be careful not to mix them!

- 1) Attach ball stud of new end links to sway bar with the supplied nut. Torque to 60 lb-ft.
Use an 18mm wrench on the stud to keep it from turning.
- 2) Attach end links to axle brackets. Torque to 60 lb-ft.

