


PowerWatch Software

Software Specifications

Type: For PowerWatch (voltage disturbance recorder)

This powerful and easy-to-use power quality analysis software program is developed exclusively for ACR's voltage disturbance recorder, the PowerWatch. With no programming hassles or complex menus, setup and downloading occurs in seconds.



DOWNLOADING AND COMMUNICATING WITH POWERWATCH

Downloading and communicating with the PowerWatch could not be more simple: plug the optical interface cable (LIC-101 cable) into the serial port of your computer and point the other end to the optical port on the PowerWatch. Communication begins immediately. No tools, cards or docking stations are required.




SETUP INFORMATION

The following setup information is displayed in PowerWatch software: voltage disturbance threshold values, site descriptions, filename, start and stop data and time, and the recorder's serial number. Configure the threshold values for each voltage disturbance type or use the industry standard default values.

DETAILED SITE REPORTS


Detailed site reports are displayed for every voltage disturbance event recorded from the PowerWatch including:

- Hot-to-Neutral and/or Neutral-to-Ground Surges
- Hot-to-Neutral and/or Neutral-to-Ground Sags
- Hot-to-Neutral and/or Neutral-to-Ground Impulses
- Outages
- Frequency Variations




STATISTICAL ANALYSIS

A large number of events can be quickly analyzed by using the Quick Summary option. Quick Summary totals all the surge, sag and impulse events and displays all of their occurrences individually in a bar graph format. This format helps determine power quality trends quickly and effectively.



EVENT DISTRIBUTION GRAPH

The Event Distribution Graph plots the magnitude of events against duration on a logarithmic scale, allowing you to determine the importance of the data (a single random event may not be as important as a cluster of events). All 4000 events can be plotted on this graph. Graph hot-to-neutral or neutral-to-ground events or show both in different colours. The CBEMA Curve can be used to determine the importance of each event.



FEATURES

- Powerful and easy to use
- Quick and simple downloads
- Detailed site reports for each voltage disturbance type
- Quick summary option
- Determine importance of each event

Model#: **Cat#:**

PW (Full Install) 34-0004
 PWV-100 (Interface 01-0060
 Package)