



VEHICLES EQUIPPED WITH A “DRIVERS INFORMATION  
CENTER” OR DIC

1. Insert key and turn to ON position so you can access Driver Information Center.
2. Press the vehicle information button until “PRESS TO RELEARN REMOTE KEY” displays
3. Press the set/reset button until “REMOTE KEY LEARNING ACTIVE” displays.
4. Press and hold the lock and unlock buttons on the first keyless remote at the same time for approximately 15 seconds. (On vehicles with memory recall seats, the first remote learned will match driver 1 and the second will match driver 2.)
5. To program additional remotes at this time, repeat step 4. This vehicle can have a maximum of eight remotes programmed.
6. To exit programming mode, **turn key off and remove key. Test remote(s).**