



**TO:** ALL AUTHORIZED SERVICE ACCOUNTS  
AS-1975 MANUAL OWNERS

**SUBJECT:** 1999 U-VAN PASSKEY III RE-PROGRAMMING

**NO:** AS-1163  
**DATE:** 6-1-98  
**FILE IN:** BULLETIN BINDER

### **PASSKey III RE-PROGRAMMING**

To re-program the 1999 PASSKey III System for the General Motors Transport, Silhouette and Venture Vans when no pre-programmed working key is available.

*Note: This procedure will erase the memory of any/all previously programmed keys.*

1. Insert an un-programmed properly cut PASSKey III key blank into the ignition. Turn from the "OFF" to the "ON" position. The security light will illuminate for approximately 10 minutes.
2. When the security light goes out, immediately turn from "ON" to "OFF," and remove the key.
3. Within 5 seconds insert the same key, and turn from "OFF" to "ON." The security light will illuminate for approximately 10 minutes.
4. When the security light goes out, immediately turn from "ON" to "OFF," and remove the key.
5. Within 5 seconds insert the same key, and turn from "OFF" to "ON." The security light will illuminate for approximately 10 minutes.
6. When the security light goes out, immediately turn from "ON" to "OFF," and remove the key.
7. Insert the same key for the fourth time and turn to the "ON" position. At this time the security light will remain off indicating successful re-programming of the system.

Additional keys can be introduced by using the "Programming additional PASSKey III Keys" process.

### **PROGRAMMING ADDITIONAL PASSKey III KEYS**

This procedure is to be used to introduce additional keys to a vehicle when a pre-programmed key is available.

1. Insert any pre-programmed PASSKey III key blank into the ignition and turn from the "OFF" to the "ON" position. The Security Light will illuminate.
2. After the Security Light extinguishes, turn from the "ON" to the "OFF" position and remove the pre-programmed key blank.
3. Within 5 seconds insert the un-programmed properly cut PASSKey III key blank into the ignition, and turn from "OFF" to "ON." The security light will extinguish when the new key blank is programmed.