


Quick Start Guide

Budget Meeting Projector - Viewsonic




Initial Setup

- 1 Make sure your projector and computer are both turned OFF
- 2 Connect VGA cable (blue) to "RGA" input on projector and VGA input on computer
- 3 Connect power cable (black) to side of projector and an electrical outlet
- 4 Flip switch above power cable input | 0 to "1"



Getting Up and Running

- 5 Remove lens cap and press STANDBY/ON button 
- 6 Turn ON your computer
- 7 Press INPUT button  until image reads, "Detecting...RGB"
- 8 If necessary, sync projector & computer by holding down FUNCTION

 and pressing one of the following keys to toggle:



Adjusting the Image

- 9 Push buttons on sides to release projector stands
- 10 Rotate FOCUS tab for optimal image clarity



NOTE: Depending on your computer, you may have to use a different F key than those listed above. If you have any problems, please give us a call at 1-877-633-8866



Quick Start Guide

Budget Meeting Projector - ViewSonic




Additional Uses

- 11 Click through PowerPoint slides by using your computer
- 12 Press MENU button on projector to bring up settings options
- 13 Use arrows on MENU button to scroll through options and adjust image settings



Powering Off

- 14 Press POWER button on projector 
- 15 When message appears, press POWER button again
- 16 Wait at least 90 seconds, then unplug projector from outlet

Troubleshooting:

- Does your image look like one of these?



- If so, here's how to fix it:
 - Press MENU button on projector
 - Scroll down to KEYSTONE
 - Adjust KEYSTONE to get desired image

If you encounter any problems whatsoever, please call us at 1-877-633-8866. We're more than happy to help!