


# Quick Start Guide

## Premium Meeting Projector - Dell 2400



### Initial Setup

- 1 Make sure your projector and computer are both turned OFF
- 2 Connect VGA cable (blue) to "VGA In" on projector and VGA input on computer
- 3 Connect power cable (black) to projector and an electrical outlet
- 4 Connect USB cable (red) to projector and any available USB port on your computer



### Getting Up and Running

- 5 Remove lens cap and press POWER button 
- 6 Turn ON your computer
- 7 Sync projector with computer by holding down the FUNCTION key  and pressing one of the following keys to toggle:



### Adjusting the Image

- 8 Push button to release stand
- 9 Slide ZOOM TAB to reach appropriate size
- 10 Rotate lens to focus



NOTE: Depending on your computer, you may have to use a different F key than those listed above. If you have any problems, please give us a call at 1-877-633-8866






# Quick Start Guide

## Premium Meeting Projector - Dell 2400




### Using the Wireless Remote

- 11 Make sure USB cable is connected to projector and a USB port on your computer (Step 4)
- 12 Press MENU or  button to adjust settings
- 13 Press PAGE buttons  and  to scroll through slides



### Powering Off

- 14 Press POWER button on projector 
- 15 When message appears, press POWER button again
- 16 Wait at least 90 seconds, then unplug projector from outlet

#### Troubleshooting:

- Does your image look like one of these?



- If so, here's how to fix it:
- Press MENU or  button
- Scroll right and select SET UP
- Adjust H. KEYSTONE and V. KEYSTONE to get desired image

If you encounter any problems whatsoever, please call us at 1-877-633-8866. We're more than happy to help!