


# Quick Start Guide

## Standard Meeting Projector - Dell 3400



### Initial Setup

- 1 Make sure your projector and computer are both turned OFF
- 2 Connect M1 cable (blue) to M1 input on projector
- 3 Connect USB plug (red) to any available USB port on your computer
- 4 Connect VGA plug (green) to VGA input on your computer
- 5 Connect power cable (black) to projector and an electrical outlet



### Getting Up and Running

- 6 Remove lens cap and press POWER button
- 7 Turn ON your computer
- 8 Sync projector with computer by holding down the FUNCTION key



and pressing one of the following keys to toggle:



### Adjusting the Image

- 9 Push button to release stand
- 10 Slide ZOOM TAB to reach appropriate size
- 11 Rotate lens to focus



NOTE: Depending on your computer, you may have to use a different F key than those listed above. If you have any problems, please give us a call at 1-877-633-8866






# Quick Start Guide

## Standard Meeting Projector - Dell 3400




### Using the Wireless Remote

- 12 Make sure USB plug is connected to a USB port on your computer (Step 3)
- 13 Press MENU or  button to adjust settings
- 14 Press PAGE buttons  and  to scroll through slides




### Powering Off

- 15 Press POWER button on projector 
- 16 When message appears, press POWER button again
- 17 Wait at least 90 seconds, then unplug projector from outlet

#### Troubleshooting:

- Does your image look like one of these?



- If so, here's how to fix it:
- Press MENU or  button
- Select IMAGE SETTINGS
- Scroll down to KEYSTONE and adjust to get desired image

If you encounter any problems whatsoever, please call us at 1-877-633-8866. We're more than happy to help!