

Quick Start Guide

Ultra High Resolution Projector - Dell 5100






Initial Setup

- 1 Make sure your projector and computer are both turned OFF
- 2 Connect M1 cable (blue) to "M1 Signal In" on projector
- 3 Connect USB plug (red) to any available USB port on your computer
- 4 Connect VGA plug (green) to VGA input on your computer
- 5 Connect power cable (black) to projector and an electrical outlet



Getting Up and Running

- 6 Remove lens cap and press POWER button 
- 7 Turn ON your computer
- 8 If necessary, sync projector & computer by holding down FUNCTION 



Adjusting the Image

- 9 Push button to release stand
- 10 Slide ZOOM TAB to reach appropriate size
- 11 Rotate lens to focus



NOTE: Depending on your computer, you may have to use a different F key than those listed above. If you have any problems, please give us a call at 1-877-633-8866







Quick Start Guide

Ultra High Resolution Projector - Dell 5100




Using the Wireless Remote

- 12 Make sure USB plug is connected to a USB port on your computer (Step 3)
- 13 Press PAGE buttons  and  to scroll through slides
- 14 Press MENU or  button to adjust advanced settings
- 15 Press the  button to use the laser pointer




Powering Off

- 16 Press POWER button on projector 
- 17 When message appears, press POWER button again
- 18 Wait at least 90 seconds, then unplug projector from outlet

Troubleshooting:

- Does your image look like one of these?



- If so, here's how to fix it:
 - Press MENU or  button
 - Select IMAGE SETTINGS
 - Adjust V. KEYSTONE and H. KEYSTONE to get desired image

If you encounter any problems whatsoever, please call us at 1-877-633-8866. We're more than happy to help!