



myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for REMINGTON MB-200. You'll find the answers to all your questions on the REMINGTON MB-200 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual REMINGTON MB-200
User guide REMINGTON MB-200
Operating instructions REMINGTON MB-200
Instructions for use REMINGTON MB-200
Instruction manual REMINGTON MB-200



[Your user manual](#)
[REMINGTON MB-200](#)

Manual abstract:

As you become familiar with the settings, you can then select your desired length setting. **Trimmer Guard Attachment** Remove trimmer guard attachment if you are: defining hairline edges such as sideburns, trimming the nape of your neck, trimming your beard line on front of neck, or if you want to clean cutter assembly. **to remove:** Be sure the trimmer is in OFF position. While holding trimmer in one hand, and holding the "Zoom Wheel" to prevent it from turning, gently pull the trimmer guard attachment away from the trimmer. The guard can be removed and replaced on any setting. While holding the trimmer in one hand, and holding the "Zoom Wheel" to prevent it from turning, slide the guard over the top of the trimmer until it "clicks" into position. **NOTE:** the trimmer guard attachment can only be placed on the trimmer one way; if it does not fit properly, remove and reverse it. Before you begin, comb your hair in the direction that it grows so that the hairs are at their maximum height and facing in the same direction. Determine how much hair you want to cut and position the hair length selector accordingly. Remember, until you are familiar with using the trimmer, it's always better to select a longer hair setting initially in order not to trim too much hair.

Turn the unit's power switch to ON, and begin trimming. When finished trimming, turn the unit's power switch to OFF. start with edge of beard line. With the cutting blades resting lightly against your skin, use motions towards edge of beard line to trim it to desired location in facial area and away from beard in neck area. With the Pop-Up Trimmer (MB-300) The small size of this trimmer makes edging and defining mustaches and cutting stray hairs quick and easy. **Remove guard attachment** Comb hairs outward so they are at their maximum height. Without trimmer guard attachment **Remove trimmer guard attachment.** Place a finger on upper lip only to lift hair up, away from skin. trim hairs using an upward motion. After achieving desired length, use a downward motion to blend mustache hairs.

NOTE: Use slow and light pressure. Too much pressure may trim off more hair than desired. Use the unit's styling comb or a small comb and hold the beard hairs in place while trimming. Holding the trimmer horizontally with the cutting unit facing away from you, move the trimmer along the length of the comb. To trim sideburns Comb sideburns following the direction of your hair growth. You will need a hand mirror for this operation if performing it alone. The mirror is not necessary if trimming is performed by a second person. remove the hair length selector attachment. Use your fingers to lift the hair at the base of your head up off the neck. Your index finger should be covering the roots of the hairs you are lifting to prevent accidental removal by trimmer.

Using your other hand, hold the trimmer horizontally to the base of your neck with the cutting unit facing up, and move the trimmer along the length of the neck until the unit touches your finger covering the hair roots at the base of your head. Repeat this procedure for the entire area of the neck. Be sure to move the unit slowly when performing this operation and to keep the hair roots at the base of your head out of the way of the trimmer. Use the hand mirror to inspect the results of the operation and ensure all hairs along the nape of the neck have been trimmed. Turn the trimmer so the front of the cutting unit ("Zoom Wheel" side) is facing away from you. Start trimming under your chin and, following your jawbone line, work toward your ear and upper beard line using an upward motion. Allow the hair length selector attachment to follow the contours of your face. You may trim either against or with the direction of beard growth, whichever is preferred. Trimmer guard attachment should be on and set to position 1 (1. Hold trimmer horizontally with the cutting unit facing either up or down.

Trim hairs using an upward or downward motion against or with the direction of hair growth, whichever is preferred. For an even closer "stubble look," remove the hair length selector attachment and repeat the previous two steps. However, caution must be taken not to remove too much hair, creating a "blotchy" look..



[Your user manual](#)
[REMINGTON MB-200](#)