

Wahl Deluxe Style Pro Clipper Quick Start Guide

1 Clipper Testing

All Wahl clippers are tested before they leave our factory. Often testing materials or grinding compound may be found on the blades. This is easily cleaned off using the enclosed blade cleaning brush.



Your Clipper



2 Oil Blades Before Each Use

Oil included with your clipper




Your Wahl clipper blades were oiled and aligned before leaving our factory. Blades may need to be realigned if they have been bumped or removed for cleaning. To determine if realignment is necessary, compare your clipper blades with this sketch in your user manual under "Clipper Maintenance." This page also features instructions on how to realign.

4 Attaching Guide Combs




Align comb on blade, then press tab until you hear a snap.

3 Taper Lever



The taper lever adds versatility to your clipper by allowing you to gradually change the closeness of your cut. (Up position = closest cut; Down position = longest cut) Should the blades become jammed with hair, move the taper lever up and down several times. This will help free up the blades.

5 Easy to Follow Instructions



Follow the easy step-by-step instruction guidebook for a perfect haircut every time.