



myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for HP OFFICEJET 4500 G510G. You'll find the answers to all your questions on the HP OFFICEJET 4500 G510G in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HP OFFICEJET 4500 G510G

User guide HP OFFICEJET 4500 G510G

Operating instructions HP OFFICEJET 4500 G510G

Instructions for use HP OFFICEJET 4500 G510G

Instruction manual HP OFFICEJET 4500 G510G



OFFICEJET 4500

Getting Started Guide

Guide de Mise en Marche

Guia de Pimeiros Passos

دليل بدء التشغيل



G510



[Your user manual](#)

[HP OFFICEJET 4500 G510G](#)

Manual abstract:

If your country/region is not listed, follow the instructions provided in this guide. If you are in one of the following countries/regions, visit the appropriate Web site for information about setting up fax. Step 1: Connect the printer to the phone line before you begin. Before beginning, be sure you have done the following: • Have the telephone cord and adapter (if provided with the printer) ready. For more information, see the setup poster included in the box with the printer. To connect the printer and any other telephone equipment or devices, complete the following steps: 1. Using the phone cord provided in the box with the printer, connect one end to your telephone wall jack, then connect the other end to the port labeled 1-LINE on the back of the printer. Note: You might need to connect the provided phone cord to the adapter provided for your country/region. 2. Note: If the phone cord that came with the printer is not long enough, you can use a coupler to extend the length.

You can purchase a coupler at an electronics store that carries phone accessories. You also need another phone cord, which can be a standard phone cord that you might already have in your home or office. For more information, see the user guide (which is available on your computer after you install the software). CAUTION: If you do not use the provided cord to connect from the telephone wall jack to the printer, you might not be able to fax successfully.

This phone cord is different from the phone cords you might already have in your home or office.

Connect any other telephone equipment. For more information about connecting and setting up additional devices or services with the printer, see the boxes in this section or see the user guide. Note: If you encounter problems setting up the printer with other equipment or services, contact the company that provided the equipment or service. Tip: If you subscribe to a voicemail service on the same phone line that you will use for faxing, you cannot receive faxes automatically. Because you must be available to respond in person to incoming fax calls, be sure to turn off the Auto Answer feature.

If you want to receive faxes automatically instead, contact your telephone company to subscribe to a distinctive ring service or to obtain a separate telephone line for faxing. 3. After you have connected the printer and any other telephone equipment, go to "Step 2: Test fax setup" on Page 10. Many phone companies offer a distinctive ring feature that allows you to have several phone numbers on one phone line. When you subscribe to this service, each number is assigned a different ring pattern. You can set up the printer to answer incoming calls that have a specific ring pattern. If you connect the printer to a line with distinctive ring, have your telephone company assign one ring pattern to voice calls and another ring pattern to fax calls. HP recommends that you request double or triple rings for a fax number. When the printer detects the specified ring pattern, it answers the call and receives the fax. If you subscribe to a DSL/ADSL service, follow these steps to connect the fax.

1. Connect the DSL/ADSL filter and telephone cord provided by your DSL/ADSL service provider between the telephone wall jack and the DSL/ADSL filter. Connect the telephone cord provided with the printer between the DSL/ADSL filter and the 1-Line port on the printer. 1 Telephone wall jack 2 DSL/ADSL filter and telephone cord (provided by your DSL/ADSL service provider) 3 Telephone cord provided in the box with the printer, connected to the 1-LINE port on the printer Remove the white plug from the port labeled 2-EXT on the back of the printer, and then connect a phone to this port. If you are connecting additional equipment, such as a dial-up computer modem or a telephone, you will need to purchase a parallel splitter. A parallel splitter has one RJ-11 port on the front and two RJ-11 ports on the back. Do not use a 2-line phone splitter, a serial splitter, or a parallel splitter which has two RJ-11 ports on the front and a plug on the back. Note: If you subscribe to a DSL/ADSL service, connect to the DSL/ADSL filter to the parallel splitter, and then use the HP-provided telephone cord to connect the other end of the filter to the 1-Line port on the printer..



[Your user manual](#)

[HP OFFICEJET 4500 G510G](#)