

"P" SERIES LIGHTS HOMEOWNER OPERATIONS INSTRUCTIONS

FOR COLOR & COLOR SHOW SELECTION

DO NOT LOSE THIS AS YOU WILL NEED IT TO REMEMBER THE POSITIONS FOR COLORS & COLOR SHOW SELECTION

We recommend that you place this next to Manual Switch used for light(s) operation.

This is primarily important for use with Manual Switches. When P Series are installed into Pentair or Zodiac T Series Controllers -color and colors shows are directly indicated by those controls

POWERING ON THE P SERIES LED LIGHTS

1. Turn the lights on and wait for 20 seconds. The lights will first come on white for a few seconds and then return to the color mode it was on prior to being turned off. (If this is the initial installation, the lights will return to whatever mode they were in when last receiving power).

WHEN OPERATED FROM WALL SWITCH OR OTHER MANUAL OFF/ON METHOD

2. To move to another color mode, Cycle the lights OFF/ON the selected number of times listed below.

Example: If you are now on BLUE (8) and want the lights to be Magenta (12), then the lights must be turned off and on (12) twelve times to bring you to Magenta.

To move to from Blue (#8) to Old School (#1) - turn OFF/ON 1 Time.

1. Old School - cycles through white,magenta,blue & green colors
2. Dance Mode: Rapid color changes
3. Smooth Mode: slow color transitions
4. Island Mode: Transitions between variety of blue and greens
5. USA Mode: Red,white and blue
6. Desert Mode:oranges, reds and magenta
7. Rich Mode: darker color shades
8. Blue
9. Green
10. Red
11. White
12. Magenta

Toggle Switch must be cycled each number of times to get to your color or color show selection.

13. Save: Saves the current color choice during a color show - see special section on SAVE usage

14. Bring Back: Turns on last saved color selection selected in Position #13

These 2 Modes are specifically used with advanced control systems and not Manual Operations

WARNING!! During the ON/OFF cycle, before the selected mode is displayed, no illumination will occur. During this period of time the pool/spa will be dark and precautions should be taken to avoid unforeseen accidents. Failure to observe this warning may result in serious injury for death to pool/spa users.

3. The lights have memory. If the lights are off for 5-10 seconds, the next time the lights are turned on, they will go to white for approximately a few seconds and then return to the last color mode they were on prior to being turned off (Step 1 listed above). This function allows you to keep your lights returning to your favorite color mode every time the lights are turned back on.