

Connector Identification and Wire Harness Routing

Connector or Terminal	Number of Cavities/ Color	Location	Connects to	Notes
-----------------------	---------------------------	----------	-------------	-------

Engine Compartment Wire Harness

C151	20-BRN	Right side of engine compartment	Main wire harness	
C152	5-BRN	Right side of engine compartment	Main wire harness	
C153	2-ORN	Right side of engine compartment	ABS pump motor	
C154	2-ORN	Right side of engine compartment	Right front ABS wheel sensor	
C155	6-GRY	Right side of engine compartment	Ignition control module (ICM)	
C156	6-GRY	Right side of engine compartment	IAB low and high control solenoid valves and PAIR control solenoid valve	
C157	3-GRY	Behind right front side marker light	Right front side marker light	
C158	2-BRN	Behind right headlight	Right front parking light	
C159	4-GRY	Behind right headlight	Right headlight	
C160	2-GRY	Behind right front bumper	Right front turn signal light	
C161	2-GRY	Behind right front bumper	Right horn	
C162	4-GRY	Behind right front bumper	A/C triple pressure switch	
C163	2-GRY	Front of engine compartment	Radiator fan control sensor	
C164	2-GRY	Front of engine compartment	Radiator fan motor	
C165	2-GRY	Front of engine compartment	Condenser fan motor	
C166	2-GRY	Middle of engine compartment	Hood switch	
C167	2-GRY	Behind middle of front bumper	Outside air temperature sensor	
G153		Right side of engine compartment	Body ground, via engine compartment wire harness	
G154		Right rear corner of engine compt.	Body ground, via engine compartment wire harness	

