

Connector Identification and Wire Harness Routing

Connector or Terminal	Number of Cavities/ Color	Location	Connects to	Notes
-----------------------	---------------------------	----------	-------------	-------

A/T Sub-harness

C182	14-GRY	Left rear corner of engine compt.	Engine compartment wire harness	
C222	4-GRY	Under rear of engine compartment	Shift control solenoid valves and linear solenoid	
C223	2-GRY	Rear center of engine compartment	Lock-up control solenoid valve	
C224	2-GRY	Rear center of engine compartment	Mainshaft speed sensor	
C225	3-GRY	Rear center of engine compartment	Countershaft speed sensor	

Knock Sensor Sub-harness

C120	3-GRY	Left rear corner of engine compartment	Engine wire harness	
C232	2-CAVITY	Under intake manifold	Left knock sensor (KS)	
C233	2-CAVITY	Under intake manifold	Right knock sensor (KS)	

