

Connector Identification and Wire Harness Routing

| Connector or Terminal | Number of Cavities/ Color | Location | Connects to | Notes |
|--|---------------------------|----------------------------------|---------------------------------------|--------|
| Main Wire Harness (Left Branch) | | | | |
| C184 | 12-BRN | Behind left kick panel | Engine compartment wire harness | A/T |
| C185 | 20-BRN | Behind left kick panel | Engine compartment wire harness | |
| C186 | 16-BRN | Behind left kick panel | Engine compartment wire harness | |
| C187 | 1-CAVITY | Behind left kick panel | Engine compartment wire harness | '93 |
| C187 | 2-CAVITY | Behind left kick panel | Engine compartment wire harness | '94 |
| C188 | 7-BRN | Behind left kick panel | Engine compartment wire harness | |
| C253 | 20-CAVITY | Under left side of dash | Left side wire harness | |
| C257 | 20-GRN | Under left side of dash | Left side wire harness | |
| C258 | 7-GRN | Under left side of dash | Left side wire harness | |
| C301 | 20-GRY | Left front door | Driver's door wire harness | |
| C302 | 18-GRN | Left front door | Driver's door wire harness | |
| C303 | 10-GRY | Left front door | Driver's door wire harness | |
| C304 | 3-BRN | Left front door | Driver's door wire harness | |
| C305 | 8-GRN | Behind left kick panel | Roof wire harness | |
| C307 | 2-CAVITY | Under left side of dash | Clutch switch (Cruise control system) | M/T |
| C308 | 8-GRY | Under left side of dash | PGM-FI main relay | |
| C309 | 4-BRN | Under left side of dash | PGM-FI main relay | |
| C310 | 2-GRY | Under left side of dash | Left foot well light | |
| C311 | 2-BLU | Under left side of dash | Cellular phone system | Option |
| C312 | 2-BLU | Under left side of dash | Cellular phone system | Option |
| C313 | 2-BLU | Under left side of dash | | Option |
| C314 | 22-GRN | Behind under-dash fuse/relay box | Integrated control unit | |
| C315 | 22-BLU | Behind left kick panel | Under-dash fuse/relay box | |
| C316 | 12-BLU | Behind left kick panel | Under-dash fuse/relay box | |
| C317 | 14-BLU | Behind left kick panel | Under-dash fuse/relay box | |
| C318 | 6-BLU | Behind left kick panel | Under-dash fuse/relay box | |
| C319 | 10-BLU | Behind left kick panel | Under-dash fuse/relay box | |
| C320 | 2-BLU | Behind left kick panel | Under-dash fuse/relay box | |
| C326 | 20-ORN | Under left side of dash | Junction connector | |
| C329 | 8-GRY | Under left side of dash | Interlock control unit | A/T |
| C330 | 2-GRY | Under left side of dash | Clutch switch wire harness | M/T |
| C331 | 20-BLK | Under left side of dash | Junction connector | |
| C333 | 20-GRY | Under middle of dash | Dashboard wire harness | |
| C334 | 12-GRN | Under middle of dash | Dashboard wire harness | '93 |
| C334 | 14-GRN | Under middle of dash | Dashboard wire harness | '94 |
| C335 | 8-GRY | Under left side of dash | Ignition switch | |
| C336 | 14-GRY/GRN | Under left side of dash | Combination light switch | |
| C337 | 10-GRY | Under left side of dash | Windshield wiper/washer switch | L |
| C337 | 14-BLU | Under left side of dash | Windshield wiper/washer switch | LS |
| C338 | 4-GRN | Under left side of dash | Brake switch | |
| C339 | 2-GRY | Under left side of dash | Chime | |
| C340 | 18-GRY | Under middle of dash | Power door lock control unit | |
| C341 | 22-GRY | Under middle of dash | Security control unit | |
| C342 | 16-GRY | Under middle of dash | Security control unit | |
| C343 | 14-CAVITY | Under middle of dash | Daytime running lights control unit | Canada |
| C344 | 10-GRN | Under middle of dash | Cellular phone system | Option |
| C345 | 7-GRN | Under middle of dash | Cellular phone system | Option |
| G301 | | Behind left kick panel | Body ground, via main wire harness | |



| | | | | |
|------|----------|-------------------------|-------------------|--|
| C330 | 2-GRY | Under left side of dash | Main wire harness | |
| C422 | 2-CAVITY | Under left side of dash | Clutch switch | |

