

Connector Identification and Wire Harness Routing

Connector or Terminal	Number of Cavities/ Color	Location	Connects to	Notes
-----------------------------	---------------------------------	----------	-------------	-------

Main Wire Harness (Right side branch)

C279	8-CAVITY	Left front corner of trunk	Left side wire harness	'93
C279	10-CAVITY	Left front corner of trunk	Left side wire harness	'94
C292	2-BRN	Left front corner of trunk	Left side wire harness	LS
C390	20-CAVITY	Right front corner of floor	Main wire harness (Right branch)	'93
C390	22-CAVITY	Right front corner of floor	Main wire harness (Right branch)	'94
C391	18-CAVITY	Right front corner of floor	Main wire harness (Right branch)	'93
C391	20-CAVITY	Right front corner of floor	Main wire harness (Right branch)	'94
C392	16-CAVITY	Right front corner of floor	Main wire harness (Right branch)	
C393	7-CAVITY	Right front corner of floor	Main wire harness (Right branch)	
C398	12-GRY	Under passenger's seat	Passenger's power seat wire harness	LS
C399	2-BRN	Under passenger's seat	Passenger's power seat wire harness	LS
C400	6-ORN	Right side of floor	ABS inspection connector	
C401	6-GRY	Center floor	Driver's seat heater switch	LS
C402	6-GRN	Center floor	Passenger's seat heater switch	LS
C403	8-GRY	Center floor	Cellular phone system	Option
C404	2-GRY	Center floor	Shift lock solenoid	A/T
C406	20-ORN	Behind right side of rear seat	ABS control unit	TCS
C406	18-ORN	Behind right side of rear seat	ABS control unit	
C407	14-ORN	Behind right side of rear seat	ABS control unit	TCS
C407	12-ORN	Behind right side of rear seat	ABS control unit	
C409	2-BRN	Fuel tank	Fuel pump	
C410	3-BRN	Fuel tank	Fuel gauge sending unit	
C411	2-ORN	Right of trunk center	ABS right rear wheel sensor	
C412	2-ORN	Left of trunk center	ABS left rear wheel sensor	
C414	3-GRY	Right quarter panel	Passenger's seat belt tension reducer	'93
C414	2-GRY	Right quarter panel	Passenger's seat belt tension reducer	'94
C415	3-YEL	Right quarter panel	Passenger's seat belt pretensioner	
C416	8-GRY	Right quarter panel	Right rear power window switch	
C417	2-BRN	Right quarter panel	Right rear window motor	
C418	6-GRY	Right quarter panel	Passenger's power door closer	
C419	3-GRY	Right side of floor	Passenger's seat belt switch	
C420	4-GRY	Right side of floor	Passenger's power seat belt pretensioner	
C423	18-GRY	Behind right side of rear seat	Power door closer control unit	
C424	16-GRY	Behind right side of rear seat	TCS control unit	LS
C425	26-GRY	Behind right side of rear seat	TCS control unit	LS
C426	3-GRY	Right front corner of trunk	Lg (lateral acceleration) sensor	LS
G304		Right side of floor	Body ground, via main wire harness	
G305		Right front corner of trunk	Body ground, via main wire harness	

