

Connector Identification and Wire Harness Routing

Connector or Terminal	Number of Cavities/ Color	Location	Connects to	Notes
-----------------------------	---------------------------------	----------	-------------	-------

Driver's Door Wire Harness

C301	20-GRY	Driver's door	Main wire harness	'93 '94
C302	18-GRY	Driver's door	Main wire harness	
C303	10-GRY	Driver's door	Main wire harness	
C304	3-GRY	Driver's door	Main wire harness	
C575	2-BRN	Driver's door	Left front speaker	
C576	8-GRY	Driver's door	Left mirror	
C577	16-GRY	Driver's door	Power window master switch	
C578	12-GRY	Driver's door	Power mirror switch	
C579	3-GRY	Driver's door	Driver's door lock switch	
C580	2-BRN	Driver's door	Power window master switch	
C581	4-GRY	Driver's door	Driver's window motor	
C582	8-CAVITY	Driver's door	Power seat memory switch	
C582	10-GRY	Driver's door	Driving position memory switch	
C583	2-BRN	Driver's door	Trunk opener switch	
C584	2-GRY	Driver's door	Driver's door courtesy light	
C585	3-GRY	Driver's door	Driver's door key cylinder switch	
C586	8-GRY	Driver's door	Driver's door lock actuator assembly	
C587	4-GRY	Driver's door	Driver's door outside handle switch	
C588	2-BLU	Driver's door	Security indicator	
C589	2-GRN	Driver's door	Left front tweeter	

Passenger's Door Wire Harness

C383	16-GRY	Passenger's door	Main wire harness	
C384	8-GRY	Passenger's door	Main wire harness	
C385	3-BRN	Passenger's door	Main wire harness	
C604	2-BRN	Passenger's door	Right front speaker	
C605	3-GRY	Passenger's door	Passenger's door lock switch	
C606	8-GRY	Passenger's door	Right mirror	
C607	8-GRY	Passenger's door	Passenger's power window switch	
C608	2-GRY	Passenger's door	Passenger's window motor	
C609	2-GRY	Passenger's door	Passenger's door courtesy light	
C610	8-GRY	Passenger's door	Passenger's door lock actuator assembly	
C611	3-GRY	Passenger's door	Passenger's door key cylinder switch	
C612	2-GRY	Passenger's door	Right front tweeter	

