

Connector Identification and Wire Harness Routing Index

A/T Sub-harness
Battery Ground Cables
Blower Wire Harness
Clutch Switch Wire Harness (M/T)
Dashboard Wire Harness
Driver's Door Wire Harness
Driver's Power Seat Wire Harness
Engine Compartment Wire Harness
Engine Ground Wire
Engine Wire Harness
Knock Sensor Sub-harness
Left Side Wire Harness
Main Wire Harness (Left Branch)

Main Wire Harness (Right Branch)
Main Wire Harness (Right side branch)
Main Wire Harness (Under-hood branch)
Moonroof Wire Harness
Passenger's Door Wire Harness
Passenger's Power Seat Wire Harness (LS)
Passenger's Power Seat Sub-harness (LS)
Rear Window Defogger Ground Wire
Rear Wire Harness
Reverse Lockout Solenoid Sub-harness (LS M/T)
Roof Wire Harness
SRS Main Harness
Starter Cables