

General Information

Chassis and Paint Codes

'91 Model	1-2e
'92 Model	1-2d
'93 Model	1-2c
'94 Model	1-2b
'95 Model	
USA	1-3a
Canada	1-5a
Identification Number Locations	1-4b

Warning/Caution Label Locations

'91-'92 Models	1-5d
'93-'94 Models	1-5b
'95 Model	1-7a
Lift and Support Points	
Lift and Safety Stands	1-9b
Floor Jack	1-9b
Towing	1-12b
Service Precautions	
Handling of Special Nuts and Bolts	1-13b