

Engine Lubrication

| | |
|--------------------------------|------|
| Special Tools | 8-2b |
| Component Location Index | 8-3b |
| Engine Oil | |
| Inspection | 8-4b |
| Replacement | 8-4b |
| Oil Filter | |
| Replacement | 8-5b |

| | |
|---------------------------------------|-------|
| Oil Pressure | |
| Testing | 8-5b |
| Oil Pan | |
| Removal | 8-6b |
| Installation | 8-8b |
| Oil Pump | |
| Component Location Index | 8-10b |
| Removal/Inspection/Installation | 8-11b |