

Differential

Special Tools	15-2b
Troubleshooting	15-3b
Maintenance	
Differential Oil	15-4b
Differential Assembly	
Removal/Installation	15-5b
Deletion of Secondary Cover	
('94-'95)	15-2a
Component Location Index	15-7b
Inspection	15-8b

Disassembly	15-10b
Reassembly	15-16b
Differential Carrier	
Tapered Roller Bearing	
Replacement	15-14b
Backlash Inspection	15-15b
Ring Gear Replacement	15-15b
Inspection ('91-'92)	15-14d

Drive Pinion	
Height Adjustment	15-24b
Ring Gear Tooth Contact	
Adjustment	15-25b
Ring Gear Backlash Adjustment ...	15-25b
Differential Case ('91)	
Disassembly	15-14e
Reassembly	15-15e