

Brakes

ABS (Anti-lock Brake System)

Special Tools	19-2b
Component Location Index	19-3b
Pedal Height	
Adjustment	19-4b
Parking Brake	
Inspection/Adjustment	19-4b
Front Brakes	
Index/Inspection	19-6b
Front Brake Pads	
Inspection/Replacement ...	19-7b
Front Caliper	
Disassembly	19-9b
Reassembly	19-10b
Front Brake Disc	
Runout Inspection	19-10b
Thickness and Parallelism	
Inspection	
'91-'92	19-11d
'93-'95	19-11b
Master Cylinder and Brake Booster	
Index/Torque	19-13b

Master Cylinder	
Inspection	19-14b
Brake Booster	
Tests	19-15b
Pushrod Clearance	
Adjustment	19-16b
Rear Brakes	
Torque/Inspection	19-17b
Rear Brake Pads	
Inspection/Replacement ...	19-18b
Parking Drum Brakes	
Component Location Index .	19-21b
Inspection	19-22b
Disassembly	19-23b
Lining Surface Break-in ...	19-25b
Rear Caliper	
Disassembly/Reassembly ..	19-26b
Rear Brake Disc	
Runout Inspection	19-28b
Thickness and Parallelism	
Inspection	19-28b

Brake Hoses/Pipes	
Inspection	19-29b
* Parking Brake Cable	
Disassembly/Assembly	19-30b
Anti-lock Brake System (ABS)	
Features/Construction/	
Operation	19-31b
Wiring/Connector Locations ...	19-46b
ALB Checker	
Function Test	19-47b
Wheel Sensor Signal	
Confirmation	19-49b
Troubleshooting	
Anti-lock Brake System (ABS)	
Indicator Light	19-50b
Symptom-to-System Chart	19-52b
Hydraulic System	
Component Location Index .	19-76b
Relieving Accumulation/	
Line Pressure	19-77b

Modulator Unit	
Replacement	19-78b
Index/Torque	19-80b
Solenoid Leak Test	19-81b
Pump Assembly	
Index/Torque	19-82b
Accumulator Disposal	19-83b
Bleeding	
Procedure	19-11b
Air Bleeding with ALB	
Checker	19-84b
Electronic Components	
ABS Control Unit	
Replacement	19-85b
Relays Inspection	19-85b
Pulsers/Wheel Sensors	
Inspection	19-86b
Wheel Sensor Replacement	19-87b

TCS (Traction Control System)

Component Location Index	19-90b
System Description	
Outline	19-91b
Construction and Function .	19-92b

Troubleshooting	
TCS Indicator Light	19-98b
Troubleshooting Guide	19-100b
TCS Switch Test	19-152b

Fail-Safe Relay Test	19-152b
Lateral Acceleration	
(Lg) Sensor Test	19-153b
TCS Control Unit Replacement .	19-153b

Steering Angle Sensor	
Replacement	19-154b
TCS Control Valve Assembly	
Removal/Installation	19-156b