

# Idle Control System

## Troubleshooting Flowchart — Clutch Switch Signal (M/T)

This signals the ECM when the clutch is engaged.

NOTE: Before troubleshooting, adjust the clutch switch (see [section 12](#)).



