



Intake Air System

System Troubleshooting Guide

NOTE:

- Across each row in the chart, the sub-systems that could be sources of a symptom are ranked in the order they should be inspected starting with ①. Find the symptom in the left column, read across to the most likely source, then refer to the page listed at the top of that column. If inspection shows the system is OK, try the next system ②, etc.
- M/T-equipped cars use an Engine Control Module (ECM). A/T-equipped cars use a Powertrain Control Module (PCM), which also controls transmission functions. When working on an A/T-equipped car, all references to ECM in this section actually refer to the PCM.

PAGE	SUB-SYSTEM	THROTTLE CABLE	THROTTLE BODY	INTAKE AIR BYPASS CONTROL SYSTEM
SYMPTOM		11-128	11-129	11-132
	WHEN COLD FAST IDLE OUT OF SPEC	③	②	①
	WHEN WARM RPM TOO HIGH	②	①	
	LOSS OF POWER		①	②