



Disassembly/Inspection

CAUTION:

- The bearing support is made of aluminum. Be careful not to damage it when servicing.
- Do not damage the lip on inner and outer seals during installation.

