




Sub-frame

Sub-frame torque sequence:



☆ CORROSION RESISTANT BOLT

Frame Repair Chart

Unit: mm (in)

φ: Inner diameter

