

Starting System

Component Location Index

- **STARTER INTERLOCK SYSTEM (M/T)**

Description, page [23-84](#)

- **CLUTCH INTERLOCK SWITCH (M/T)**

Test, page [23-88](#)

Switch Position Adjustment, [section 12](#)

