

Gauge Assembly

Disassembly

NOTE:

- Handle the terminals and printed circuit boards carefully to avoid damaging them.
- Replace the odometer and trip meter as a unit if either of them is faulty.

